



Computer Security Products, Inc.

Qualtec® 10401/10404 Installation Instructions

These instructions to be used when using the Industrial Adhesive only.
Heavy Duty Cable System

1. Disconnect all electrical power.
2. Select a suitable location for the placement of the STEEL-LOK plate(s). Be sure to place it on a flat, solid surface near the back/side of the equipment. Do not adhere the plate over vent holes or on removable parts such as input device compartment covers. After determining the proper position, draw a pencil outline around the plates.
3. Rub the mounting surface with the green scrub provided. Dust off the surface and clean with the alcohol pad provided. Allow surface to dry 5 minutes.
4. Apply 7 drops of the liquid “Super Bond” adhesive to the surface of the plate. **CAUTION: Adhesive dries quickly and will bond to any surface. Avoid contact with skin and eyes.**
5. Immediately place plate within the penciled areas on your equipment. Apply constant light pressure to the plates for at least 1 minute. Let adhesive dry for 15 minutes before proceeding with remaining instructions.
6. Weave the small fitting of the cable through the plates. Once the cable is inserted into the last plate, slide the cable over in the slot and attach the lock as illustrated in the close up figure to the right.

