



Computer Security Products Inc.

CSP-4050/4051 Laptop Tie-Down Bracket Installation Instructions



Fig. 1

STEP 1 - Open the package and make sure that you have all the parts identified in the picture on the left (locking bracket, locking post, bushing with holes, bushing without holes, and keys). (Fig.1)




Fig. 2

STEP 2 - Choose a comfortable position for your laptop on a tabletop support and mark a location where it would be possible to drill a hole for the bushing. Drill this hole at least 9" away from any table edges.

STEP 3 - Once a hole is drilled, make sure the bottom of the table is flat and clean of any dust or debris. Fit the bushing with holes snugly into the drilled hole so that the circular part is flush against the tabletop. Fasten with screws to secure the bushing (screws are not included). (Fig. 2)



Fig. 3

STEP 4 - Slide the locking post up through the bushing so that the circular part is flush against the underside of the table. Fasten with screws to secure the post. (Fig. 3)



Fig. 4

STEP 5 - Slide the bushing without holes onto the post so that the circular parts of both bushings are touching. Slide the locking bracket onto the locking post so that the laptop screen is through the opening. Push the locking bracket down until it is resting on top of the bushing and turn the key to lock and secure your laptop. (Fig. 4)

****NOTE: Any attempt at this point to remove the laptop without first unlocking the bracket will result in damage to the computer.**

To unlock, turn the key clockwise and lift the locking bracket up off of the locking post. Keep keys in a safe place away from your computer.