



Computer Security Products Inc.

## Full Metal Jacket Enclosure Installation Instructions:

### **Preparing for the installation of the “Universal” Protector Series:**

First try a dry run by positioning the Security Unit in its intended location. Be satisfied that it will fit properly with adequate ventilation and space to slide the PC in and out and adequate space to attach monitor cables (also provide ample room to place a monitor on top of the Desktop Model and keyboard in front of it).

### **Desktop, Side, Floor, or Suspension Bolt Mounting:**

After determining the location of the unit, check where the bolts would come out to make sure that there are no obstructions and that the carriage bolt head will not interfere with any drawer movement.

Carriage bolts are supplied for 1/4” through-hole mounting. **If using heavy-duty screws to mount under a desk, make sure the screws are not long enough to come through the top of the desk**

### **For Desktop Mounting with 3M Brand adhesive tape:**

This tape adheres best to a smooth, flat, nonporous surface. Painted surfaces are not recommended, unless baked-on or power coated. The mounting surface should be pre-cleaned. For best results, just prior to installation, wipe the surface with ordinary Isopropyl “rubbing” alcohol and dry with a clean cloth. After determining the location of the unit, remove the protective covering from the adhesive on the underside of the unit. Carefully set the steel cage on the clean, prepared surface on its rear edge and bring it down forward into its desired location. Once full contact is made, using a roller or your hands, apply firm and uniform pressure in repeated passes over the entire base to achieve the best possible bond. 3M recommends 72 hrs. for a complete adhesive cure.

### **Securing the computer inside the “Universal” Protector Series:**

After proper and secure mounting of the unit, either slide the computer into it and attach the PC cables from the rear, or first pull the PC cables through the rear of the unit and attach them to the computer. After the cables are connected, slide the PC into the Security Unit and lock the Locking/Blocking device.

Your Computer is now secure!